SLONI

For an active childhood

Maly Pikler Triangle



ASSEMBLY INSTRUCTIONS

Maly Pikler Triangle
ASSEMBLY INSTRUCTIONS

WARNING:

Suitable for children aged 10 months and over.
Use only under adult supervision.
Small parts may pose a choking hazard.
The assembly is best carried out by two adults.

IMPORTANT INSTALLATION INSTRUCTIONS.
PLEASE READ THESE INSTRUCTIONS CAREFULLY AND FOLLOW EVERY STEP EXACTLY.

Recommended age and intended use

Suitable for children aged 10 months and over. Please take your child's individual stage of development into account. The Pikler Triangle Maly is intended exclusively for climbing, grasping, pulling oneself up, balancing and age-appropriate movement games in private indoor settings.

Maximum load capacity: 30 kg

The specified maximum load capacity must not be exceeded.

Warning: Use only under the direct supervision of an adult.

Assembly and safety instructions

The assembly parts contain small parts that could be swallowed. Assembly must only be carried out by adults. Keep children away from the assembly parts whilst assembly is taking place. Assemble the product fully and carefully in accordance with the enclosed assembly instructions. The Pikler Triangle Maly must only be used on a level, dry and non-slip surface.


Check regularly that all screws and joints are tightened securely, that all rungs and other components are firmly in place, and that the Pikler triangle is stable and secure; retighten the screw joints if necessary.

Folding and adjusting

Only adults are permitted to open, close and adjust the angle. Children must keep a safe distance whilst this is being done.

Care instructions


Clean the wood with a soft, dry or slightly damp cloth and then wipe it dry.
Do not use harsh or abrasive cleaning products and avoid prolonged exposure to moisture.




Last updated: 10/2026 v1.01

Contents of the package


Your parcel contains the following:




1 x side panel A




1 x side panel C




1 x side panel B




1 x side panel D



6 x rung A (short)




7 x rung B (long)




26 x screw A




2 x knurled screw B



Step 1



1 x side panel A




1 x side panel B

6 x rung A




12 x screw A


Insert the six short rungs A into the designated holes in side panel A (1). Place side panel B onto the free ends of the rungs (2). Secure each rung on both sides using the twelve screws A (3).



(1)




(2)




(3)


Step 2




1 x rung B

Slide a long rung B through the top two holes of the assembled frame. The rung must protrude on both sides.







Step 3



1 x side panel C




1 x side panel D




6 x rung B

Slide side panel C onto the protruding end of the long rung B (1). Insert the remaining six long rungs B into the designated openings in side panel C. Then place side panel D onto the free ends of all seven rungs (2).



(1)




(2)

Step 4




14 x screw A

First, secure the top long rung B on both sides with one screw A on each side (1).
The screws need a little play here so that you can open the triangle. Then secure the remaining six long rungs on both sides with the twelve remaining screws A (2).



(1)




(2)

Step 5




2 x knurled screw B

Set up the Pikler triangle and adjust it to the desired opening angle. Select the same hole position on both sides for the two knurled screws B and screw them into the pre-drilled holes.




Step 6

You can fold up your Pikler triangle to save space by turning the knurled screws to their outermost position.



Step 7

Congratulations, your Maly Pikler triangle is ready to use.
We hope you enjoy it.



SLONI

For an active childhood

Quality meets design


Of course, we want only the best for your child. Climbing promotes children's physical and mental development in a playful way. Our products are lovingly handcrafted from solid pine and beech wood, are untreated and, naturally, free from harmful substances. And, just like you, we love good design. That's why we founded SLONI. Find out more at sloni.de.



Climbing walls



Climbing triangles



Bouldering walls

Sloni GmbH

Maysweg 10
47918 Tönisvorst
Germany
Phone: +49 2151 51 65 00
Email: info@sloni.de