SLONI

For an active childhood

Vika Pikler Triangle



ASSEMBLY INSTRUCTIONS

VIKA PIKLER TRIANGLE
ASSEMBLY INSTRUCTIONS

WARNING:

Suitable for children aged 1 to 4.
Use only under adult supervision.
Small parts may pose a choking hazard.
The assembly is best carried out by two adults.

IMPORTANT INSTALLATION INSTRUCTIONS.
PLEASE READ THESE INSTRUCTIONS CAREFULLY AND FOLLOW EVERY STEP EXACTLY.

Recommended age and intended use

Suitable for children aged approximately 1 to 4 years. Please take your child's individual stage of development into account. The Vika Pikler Triangle is intended solely for climbing, grasping, pulling oneself up, balancing and age-appropriate movement games in private indoor settings.

Maximum load capacity: 40 kg

Warning: To be used only under the direct supervision of an adult.

Installation and safety instructions

Assembly must only be carried out by adults. Keep assembly materials and small parts out of the reach of children. Assemble Vika in full accordance with the enclosed assembly instructions and use it only on a level, dry and non-slip surface.


Before each use, check that all screws and joints are tightened securely, that all rungs, the climbing net and the wooden platform are securely fastened, and that Vika is stable and shows no visible damage.

Turning round and changing the side on which you are active

Vika can be turned over and used on three different activity sides. Only an adult should turn it over or change its position. Before each use, make sure that Vika is standing firmly and stably on the floor.

Care instructions


Clean the wood with a soft, dry or slightly damp cloth, then dry it thoroughly. Do not use harsh or abrasive cleaning products, and avoid prolonged exposure to moisture.




Last updated: 10/2026 v1.02

Contents of the package


Your parcel contains the following:




1 x climbing frame A



1 x climbing frame B




1 x climbing frame C




6 x connector



3 x rungs




24 x screw A with sleeve



6 x screw B


Step 1




6 x connector

3 x rungs

Take the 6 connectors and the three rungs. Place one rung between each pair of connectors and secure it with screws B. Repeat this with all 3 rungs.



Step 2





1 x climbing frame A




8 x screws with sleeves


Now take the pre-assembled climbing element A and attach it to the triangular connecting pieces as shown. Ensure that the element is correctly aligned and sits flush against the sides. Then secure it firmly using the screws and sleeves provided to ensure a stable connection.







Step 3




1 x climbing frame B




4 x screws with sleeves

Now take climbing element B and attach it to the triangular connectors as shown in step 2. Make sure that the element is correctly aligned and sits flush against the sides. Then secure it firmly using the screws and sleeves provided to ensure a stable connection.





Step 4





1 x climbing frame C



4 x screws with sleeves


Now take the third pre-assembled climbing element C and attach it to the triangular connector as shown in the illustration. Align the element as shown in the illustration and screw it in place as before using the screws and sleeves provided. Ensure that all connections are tightened securely and that the climbing element is firmly in place.






Step 5

Now take the final component from step 1 and attach it to the climbing frames using the screws and sleeves provided, until all joints are secure. Finally, check that all screws are tightened securely and that all joints are firmly in place. Check the stability of the Pikler triangle before using it.



Step 6

Congratulations, your Vika Pikler triangle is ready to use.
We hope you enjoy using it.



SLONI

For an active childhood

Quality meets design


Of course, we want only the best for your child. Climbing promotes children's physical and mental development in a playful way. Our products are lovingly handcrafted from solid pine and beech wood, are untreated and, naturally, free from harmful substances. And, just like you, we love good design. That's why we founded SLONI. Find out more at sloni.de.



Climbing walls



Climbing triangles



Bouldering walls

Sloni GmbH

Maysweg 10
47918 Tönisvorst
Germany
Phone: +49 2151 51 65 00
Email: info@sloni.de